



Installation Instructions for ISO Care Unit

1. The ISO-CARE unit ships completely assembled. Plastisol-coated mesh floor just needs to be set in place, inside each unit after unpacking.
2. Once the unit is set in the desired location it is ready to be vented and plumbed.
3. Each unit is equipped with a 120v fan/light combination that is rated 1.6amps.
4. 4” flex duct should be used to complete the exhaust ductwork. The ductwork attaches to the top of each unit and then you must route the ductwork to your vented location.
5. 2” PVC fittings and pipes are required to plumb each unit to your drain location as needed.
6. Each unit is to be plugged into a grounded wall outlet.
7. Each unit is equipped with an independent switch for both the light and fan. The switch is conveniently located on the front of the unit.